Scheduled Maintenance

Follow Schedule 1 if the vehicle is operated mainly where none of the following conditions apply.
If any do apply, follow Schedule 2 (Canada and Puerto Rico residents follow Schedule 2).

- Repeated short-distance driving
- Driving in dusty conditions
- Driving with extended use of brakes
- Driving in areas where salt or other corrosive materials are being used
- Driving on rough or muddy roads
- Extended periods of idling or low-speed operation
- Driving for long periods in cold temperatures or extremely humid climates

NOTE
After the prescribed period, continue to follow the described maintenance at the recommended intervals.

▼Schedule 1

I : Inspect and repair, clean, adjust, or replace if necessary.
R: Replace
L: Lubricate

Maintenance Interval (Number of months or kilometers (miles), whichever comes first)	**Months**	**6**	**12**	**18**	**24**	**30**	**36**	**42**	**48**
	×1000 km	**12**	**24**	**36**	**48**	**60**	**72**	**84**	**96**
	×1000 miles	**7.5**	**15**	**22.5**	**30**	**37.5**	**45**	**52.5**	**60**

ENGINE

Drive belts (tension)	2.3-liter engine					**I**			
	3.0-liter engine				**I**				**I**
Engine oil		**R**	**R**	**R**	**R**	**R**	**R**	**R**	**R**
Engine oil filter		**R**	**R**	**R**	**R**	**R**	**R**	**R**	**R**

COOLING SYSTEM

Cooling system				**I**				**I**
Engine coolant	**Replace at first 168,000km (105,000miles) or 60 months ; after that, every 48,000km (30,000miles) or 24 months**							

FUEL SYSTEM

Air filter					**R**			
Fuel lines and hoses*1				**I**				**I**
Hoses and tubes for emission*1								**I**

IGNITION SYSTEM

Spark plugs	**Replace every 120,000km (75,000miles)**

CHASSIS and BODY

Brake lines, hoses and connections				**I**				**I**
Disc brakes		**I**		**I**		**I**		**I**
Steering operation and linkages				**I**				**I**
Front suspension ball joints				**I**				**I**
Driveshaft dust boots				**I**				**I**
Bolts and nuts on chassis and body				**I**				**I**
Exhaust system heat shields				**I**				**I**
All locks and hinges	**L**	**L**	**L**	**L**	**L**	**L**	**L**	**L**

AIR CONDITIONER SYSTEM (if installed)

Cabin air filter	**Replace every 40,000km (25,000miles) or 24 months**

*1 According to state/provincial and federal regulations, failure to perform maintenance on these items will not void your emissions warranties. However, Mazda recommends that all maintenance services be performed at the recommended time or mileage/kilometer period to ensure long-term reliability.

▼Schedule 2

I : Inspect and repair, clean, adjust, or replace if necessary.
R: Replace

Maintenance Interval (Number of months or kilometers (miles), whichever comes first)													
	Months	**4**	**8**	**12**	**16**	**20**	**24**	**28**	**32**	**36**	**40**	**44**	**48**
	×1000 km	**8**	**16**	**24**	**32**	**40**	**48**	**56**	**64**	**72**	**80**	**88**	**96**
	×1000 miles	**5**	**10**	**15**	**20**	**25**	**30**	**35**	**40**	**45**	**50**	**55**	**60**

ENGINE

Drive belts (tension)	2.3-liter engine							**I**					
	3.0-liter engine						**I**						**I**
Engine oil	Puerto Rico	**Replace every 5,000km (3,000miles) or 3 months**											
	Others	**R**	**R**	**R**	**R**	**R**	**R**	**R**	**R**	**R**	**R**	**R**	**R**
Engine oil filter		**R**	**R**	**R**	**R**	**R**	**R**	**R**	**R**	**R**	**R**	**R**	**R**

COOLING SYSTEM

Cooling system							**I**						**I**
Engine coolant	**Replace at first 168,000km (105,000miles) or 60 months ; after that, every 48,000km (30,000miles) or 24 months**												
Engine coolant level	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**

FUEL SYSTEM

Air filter	Puerto Rico						**R**						
	Others							**R**					
Fuel lines and hoses*1							**I**						**I**
Hoses and tubes for emission*1													**I**

IGNITION SYSTEM

Spark plugs	USA	**Replace every 96,000km (60,000miles)**
	Others*2	**Replace every 120,000km (75,000miles)**

ELECTRICAL SYSTEM

Function of all lights	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**

*1 According to state/provincial and federal regulations, failure to perform maintenance on these items will not void your emissions warranties. However, Mazda recommends that all maintenance services be performed at the recommended time or mileage/kilometer period to ensure long-term reliability.

*2 If the vehicle is operated under any of the following conditions, change the spark plugs every 96,000 km(60,000 miles) or shorter.
a)Repeated short-distance driving
b)Extended periods of idling or low-speed operation
c)Driving for long periods in cold temperatures or extremely humid climates

Maintenance and Care

I : Inspect and repair, clean, adjust, or replace if necessary.
L: Lubricate

Maintenance Interval (Number of months or kilometers (miles), whichever comes first)													
	Months	**4**	**8**	**12**	**16**	**20**	**24**	**28**	**32**	**36**	**40**	**44**	**48**
	×1000 km	**8**	**16**	**24**	**32**	**40**	**48**	**56**	**64**	**72**	**80**	**88**	**96**
	×1000 miles	**5**	**10**	**15**	**20**	**25**	**30**	**35**	**40**	**45**	**50**	**55**	**60**

CHASSIS and BODY

Brake lines, hoses and connections						**I**						**I**
Brake and clutch fluid level	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**
Disc brakes			**I**			**I**			**I**			**I**
Tire inflation pressure and tire wear	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**
Steering operation and linkages						**I**						**I**
Power steering fluid level	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**
Front suspension ball joints						**I**						**I**
Driveshaft dust boots						**I**						**I**
Bolts and nuts on chassis and body			**I**			**I**			**I**			**I**
Exhaust system heat shields						**I**						**I**
All locks and hinges	**L**	**L**	**L**	**L**	**L**	**L**	**L**	**L**	**L**	**L**	**L**	**L**
Washer fluid level	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**	**I**

AIR CONDITIONER SYSTEM (if installed)

Cabin air filter	**Replace every 40,000km (25,000miles) or 24 months**