# Scheduled Maintenance

Follow Schedule 1 if the vehicle is operated mainly where none of the following conditions apply.
If any do apply, follow Schedule 2 (Canada and Puerto Rico residents follow Schedule 2).

- Repeated short-distance driving
- Driving in dusty conditions
- Driving with extended use of brakes
- Driving in areas where salt or other corrosive materials are being used
- Driving on rough or muddy roads
- Extended periods of idling or low-speed operation
- Driving for long periods in cold temperatures or extremely humid climates

| **NOTE** |
| --- |
| After the prescribed period, continue to follow the described maintenance at the recommended intervals. |

## ▼Schedule 1

| Maintenance Interval | | Number of months or kilometers (miles), whichever comes first | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | **Months** | **6** | **12** | **18** | **24** | **30** | **36** | **42** | **48** |
| | **×1000 km** | **12** | **24** | **36** | **48** | **60** | **72** | **84** | **96** |
| | **×1000 miles** | **7.5** | **15** | **22.5** | **30** | **37.5** | **45** | **52.5** | **60** |
| **ENGINE** | | | | | | | | | |
| Engine oil | | R | R | R | R | R | R | R | R |
| Engine oil filter | | R | R | R | R | R | R | R | R |
| Drive belt | | | | | I | | | | I |
| **AIR FILTER** | | | | | | | | | |
| Air filter | | | C | | C | R | | C | |
| **IGNITION SYSTEM** | | | | | | | | | |
| Spark plugs | | | | | | R | | | |
| **FUEL SYSTEM** | | | | | | | | | |
| Fuel filter | | Replace every 160,000 km (100,000 miles) | | | | | | | |
| Fuel lines, hoses and connections*1 | | | | | I | | | | I |
| **COOLING SYSTEM** | | | | | | | | | |
| Cooling system | | | | | I | | | | I |
| Engine coolant | FL22 type*2 | Replace at first 192,000 km (120,000 miles) or 120 months ; after that, every 96,000 km (60,000 miles) or 60 months | | | | | | | |
| | Others | Replace at first 96,000 km (60,000 miles) or 48 months ; after that, every 24 months | | | | | | | |
| **CHASSIS and BODY** | | | | | | | | | |
| Brake line, hoses and connection | | | | | I | | | | I |
| Disc brakes | | | I | | I | | I | | I |
| Tire (rotation) | | Rotate every 12,000 km (7,500 miles) | | | | | | | |
| Steering operation and linkages | | | | | I | | | | I |
| Front and rear suspension and ball joints | | | | | I | | | | I |
| Manual transmission oil | | | | | | | | | R |
| Rear differential oil | | | | | | | | | R |
| Driveshaft dust boots | | | | | I | | | | I |
| Exhaust system and heat shields | | Inspect every 72,000 km (45,000 miles) or 60 months | | | | | | | |
| All locks and hinges | | L | L | L | L | L | L | L | L |
| Flat tire repair kit*3 | | Inspect every year | | | | | | | |

| Maintenance Interval | Number of months or kilometers (miles), whichever comes first | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | **Months** | **6** | **12** | **18** | **24** | **30** | **36** | **42** | **48** |
| | **×1000 km** | **12** | **24** | **36** | **48** | **60** | **72** | **84** | **96** |
| | **×1000 miles** | **7.5** | **15** | **22.5** | **30** | **37.5** | **45** | **52.5** | **60** |
| **AIR CONDITIONER SYSTEM** | | | | | | | | | |
| Cabin air filter (if installed) | | Replace every 40,000 km (25,000 miles) or 24 months | | | | | | | |

**Chart symbols**

**I:** Inspect and repair, clean, adjust, or replace if necessary.
**R:** Replace
**L:** Lubricate
**C:** Clean

**Remarks**

*1 According to state/provincial and federal regulations, failure to perform maintenance on these items will not void your emissions warranties. However, Mazda recommends that all maintenance services be performed at the recommended time or mileage/kilometer period to ensure long-term reliability.
*2 Use FL22 type coolant in vehicles with the inscription “FL22” on the radiator cap itself or the surrounding area. Use FL22 when replacing the coolant.
*3 Check the tire repair fluid expiration date every year when performing the periodic maintenance. Replace the tire repair fluid bottle with new one before the expiration date.

## ▼Schedule 2

| Maintenance Interval | | Number of months or kilometers (miles), whichever comes first | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | **Months** | **4** | **8** | **12** | **16** | **20** | **24** | **28** | **32** | **36** | **40** | **44** | **48** |
| | **×1000 km** | **8** | **16** | **24** | **32** | **40** | **48** | **56** | **64** | **72** | **80** | **88** | **96** |
| | **×1000 miles** | **5** | **10** | **15** | **20** | **25** | **30** | **35** | **40** | **45** | **50** | **55** | **60** |
| **ENGINE** | | | | | | | | | | | | | |
| Engine oil | Puerto Rico | Replace every 5,000 km (3,000 miles) or 3 months | | | | | | | | | | | |
| | Others | R | R | R | R | R | R | R | R | R | R | R | R |
| Engine oil filter | | R | R | R | R | R | R | R | R | R | R | R | R |
| Drive belt | | | | | | | I | | | | | | I |
| **AIR FILTER** | | | | | | | | | | | | | |
| Air filter | | | | C | | | C | R | | | C | | |
| **IGNITION SYSTEM** | | | | | | | | | | | | | |
| Spark plugs | | | | | | | | R | | | | | |
| **FUEL SYSTEM** | | | | | | | | | | | | | |
| Fuel filter | | Replace every 160,000 km (100,000 miles) | | | | | | | | | | | |
| Fuel lines, hoses and connections*1 | | | | | | | I | | | | | | I |
| **COOLING SYSTEM** | | | | | | | | | | | | | |
| Cooling system | | | | | | | I | | | | | | I |
| Engine coolant | FL22 type*2 | Replace at first 192,000 km (120,000 miles) or 120 months ; after that, every 96,000 km (60,000 miles) or 60 months | | | | | | | | | | | |
| | Others | Replace at first 96,000 km (60,000 miles) or 48 months ; after that, every 24 months | | | | | | | | | | | |
| Engine coolant level | | I | I | I | I | I | I | I | I | I | I | I | I |
| **ELECTRICAL SYSTEM** | | | | | | | | | | | | | |
| Function of all lights | | I | I | I | I | I | I | I | I | I | I | I | I |

| Maintenance Interval | Number of months or kilometers (miles), whichever comes first | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | **Months** | **4** | **8** | **12** | **16** | **20** | **24** | **28** | **32** | **36** | **40** | **44** | **48** |
| | **×1000 km** | **8** | **16** | **24** | **32** | **40** | **48** | **56** | **64** | **72** | **80** | **88** | **96** |
| | **×1000 miles** | **5** | **10** | **15** | **20** | **25** | **30** | **35** | **40** | **45** | **50** | **55** | **60** |
| **CHASSIS and BODY** | | | | | | | | | | | | | |
| Brake line, hoses and connection | | | | | | | I | | | | | | I |
| Brake and clutch fluid level | | I | I | I | I | I | | I | I | I | I | I | |
| Brake fluid | | | | | | | R | | | | | | R |
| Disc brakes | | | | I | | | I | | | I | | | I |
| Tire (rotation) | | Rotate every 8,000 km (5,000 miles) | | | | | | | | | | | |
| Tire inflation pressure and tire wear | | I | I | I | I | I | I | I | I | I | I | I | I |
| Steering operation and linkages | | | | | | | I | | | | | | I |
| Front and rear suspension and ball joints | | | | | | | I | | | | | | I |
| Manual transmission oil | | | | | | | R | | | | | | R |
| Rear differential oil | | | | | | | R | | | | | | R |
| Driveshaft dust boots | | | | | | | I | | | | | | I |
| Exhaust system and heat shields | | Inspect every 72,000 km (45,000 miles) or 60 months | | | | | | | | | | | |
| All locks and hinges | | L | L | L | L | L | L | L | L | L | L | L | L |
| Washer fluid level | | I | I | I | I | I | I | I | I | I | I | I | I |
| Flat tire repair kit*3 | | Inspect every year | | | | | | | | | | | |
| **AIR CONDITIONER SYSTEM** | | | | | | | | | | | | | |
| Cabin air filter (if installed) | | Replace every 40,000 km (25,000 miles) or 24 months | | | | | | | | | | | |

**Chart symbols**

**I:** Inspect and repair, clean, adjust, or replace if necessary.
**R:** Replace
**L:** Lubricate
**C:** Clean

**Remarks**

*1 According to state/provincial and federal regulations, failure to perform maintenance on these items will not void your emissions warranties. However, Mazda recommends that all maintenance services be performed at the recommended time or mileage/kilometer period to ensure long-term reliability.
*2 Use FL22 type coolant in vehicles with the inscription “FL22” on the radiator cap itself or the surrounding area. Use FL22 when replacing the coolant.
*3 Check the tire repair fluid expiration date every year when performing the periodic maintenance. Replace the tire repair fluid bottle with new one before the expiration date.